

- GROUND (CHASSIS)
- + 12v ignition turn-on
- MASTER FUSE

- SOURCE INPUT
- CONTROL OUT
- AUX LINE OUT
- (SPEAKER OUT