

- + 12V (BATTERY POSITIVE)
- GROUND (CHASSIS)
- + 12V IGNITION TURN-ON
- MASTER FUSE

- SOURCE INPUT
- CONTROL OUT
- AUX LINE DUT
- (I) SPEAKER OUT